

# NIGHT DEPOSITORY REPLACEMENT GUIDE

**BEST  
- IN -  
CLASS**

With Hamilton's 98RH and 80UC, you can replace virtually any night head without having to replace the safe.

## Hamilton's 98RH depository head is UL Listed

- Stainless steel all weather construction
- Does not require structural changes to the building or masonry
- Replaces Mosler, LeFebure, Diebold and other brands
- Ideal upgrade where UL specifications must be met
- Provides substantial cost savings as you don't have to replace the chute and safe

## Hamilton's 80UC Depository Head

- Industry standard for 35 years
- Maintenance free stainless-steel exterior
- Designed for both Drive-up and Walk-up applications
- Contains Anti-fish, embedded alarm system and physical security shield protection features
- Weather-seal kit included
- 80UC night head can be combined with a safe and chute to form a complete integrated depository system



**"Best in Class"  
for Replacement  
Night Head Solution**

est. 1967

**HAMILTON**  
CUSTOM MADE SECURITY

# Night Depository Replacement Guide



**Lefebure - 101**  
 Replace With: 98RH  
 Kit: N/A  
 Instructions: N/A



**Lefebure - 201**  
 Replace With: 98RH  
 Kit: N/A  
 Instructions: N/A



**Lefebure - 312**  
 Replace N/A  
 Kit: N/A  
 Instructions: N/A



**Lefebure - 412**  
 Replace 80UC  
 Kit: B6883  
 Instructions: N/A



**Lefebure - 577**  
 Replace N/A  
 Kit: N/A  
 Instructions: N/A



**Lefebure - 612**  
 Replace With: 98RH  
 Kit: B6357  
 Instructions: Doc #08-327



**Mosler Magna  
 Bag Only**  
 Replace: With 98RH  
 Kit: B6379  
 Instructions: 08-328



**Allied - Nightwatch  
 Dual**  
 Replace With: 98RH  
 Kit: 96-440  
 Instructions: N/A



**American Vault - 85**  
 Replace With: 80UC  
 Kit: B6883  
 Instructions: N/A



**Chubb/Diebold-  
 Citadel**  
 Replace With: 80UC  
 Kit: N/A  
 Instructions: N/A



**Collier - ND1000**  
 Replace With: 98RH  
 Kit: 96-449  
 Instructions: N/A



**Collier - ND2000/  
 ND2010**  
 Replace With: 80UC  
 Kit: 96-475  
 Instructions: N/A



**Diebold Eagle  
 Bag Only**  
 Replace With: 98RH  
 Kit: Not Needed  
 Instructions: N/A



**Diebold- Eagle 103  
 Dual Flush**  
 Replace With: 98RH  
 Kit: None Needed  
 Instructions: Doc  
 #08-326



**Diebold - Eagle 103  
 Dual Recessed**  
 Replace With: 98RH  
 Kit: N/A  
 Instructions: N/A



**Diebold - Polaris  
 Flush**  
 Replace With: 98RH  
 Kit: B6358  
 Instructions: Doc  
 #08-325



**Diebold - Polaris  
 Flush Bag Only**  
 Replace With: 98RH  
 Kit: None Needed  
 Instructions: N/A



**Diebold - Polaris  
 Recessed**  
 Replace With: 98RH  
 Kit: B6406  
 Instructions: N/A



**Diebold - Securomatic**  
 Replace With: 80UC (98RH)  
 Kit: 96-451 (B10374)  
 Instructions: Doc  
 #08-323

# Night Depository Replacement Guide



**Diebold – Cashgard**  
 Replace With: 80UC  
 Kit: B6883  
 Instructions: N/A



**Fortis – AHD106**  
 Replace With: 80UC  
 Kit: N/A  
 Instructions: N/A



**Fortis – AHDR 509**  
 Replace With: 98RH  
 Kit: N/A  
 Instructions: N/A



**Hamilton – 68F**  
 Replace With: 98RH  
 Kit: N/A  
 Instructions: N/A



**Hamilton – 67R**  
 Replace With: 98RH  
 Kit: N/A  
 Instructions: N/A



**Hamilton – 68B**  
 Replace With: 98RH  
 Kit: N/A  
 Instructions: N/A



**Mosler- American**  
 Replace: 98RH  
 Kit: B6379  
 Instructions: 08-328



**Mosler – C77-DF**  
 Replace With: 98RH  
 Kit: B6387  
 Instructions: Doc  
 #08-329



**Mosler – C77-DR**  
 Replace With: 98RH  
 Kit: B6394  
 Instructions: Doc  
 #08-330



**Mosler – C77- ER**  
 Replace With: N/A  
 Kit: N/A  
 Instructions: N/A



**Mosler – Century**  
 Replace With: 98RH  
 Kit: 96-470  
 Instructions: Doc  
 #08-331



**Mosler Magna  
 Dual Recessed**  
 Replace: 80UC  
 Kit: 96-450  
 Instructions: N/A



**Mosler – Universal**  
 Replace With: N/A  
 Kit: N/A  
 Instructions: N/A



**National – Flush**  
 Replace With: 98RH  
 Kit: N/A  
 Instructions: N/A



**National-Recessed**  
 Replace With: 98RH  
 Kit: N/A  
 Instructions: N/A



**Security  
 Corporation – ND-11**  
 Replace With: 98RH  
 Kit: 96-448  
 Instructions: N/A



**SSE**  
 Replace With: 98RH  
 Kit: N/A  
 Instructions: N/A



**SSE – Replacement  
 Head**  
 Replace With: N/A  
 Kit: N/A  
 Instructions: N/A



**Kumahira – ND-61**  
 Replace With: N/A  
 Kit: N/A  
 Instructions: N/A



**Securifort**  
 Replace With: 98RH-20  
 Kit: 14-012-CANADA  
 Instructions: 14-012 USA

# Night Depository Replacement Guide



**National – Flush**  
 Replace with: 98RH  
 Kit: N/A  
 Instructions: N/A



**National – Recessed**  
 Replace with: 98RH  
 Kit: N/A  
 Instructions: N/A



**Chubb "T" Trap**  
 Replace with: 98RH-20  
 Kit: 96-798 CANADA  
 Kit: 96-959 USA



**TANN-NDH-100**  
 Replace with: 98RH-20  
 Kit: 96-919 CANADA  
 Instructions: N/A



**Chubb – Citadel c6**  
 Replace with: 98RH-20  
 Kit: 96-813 USA  
 Kit: 96-794 CANADA



**MGM**  
 Replace with: 98RH-20  
 Kit: 96-705  
 Instructions: N/A



**American 85–  
 Short (Waco)**  
 Replace with: N/A  
 Kit: 14-005 CANADA  
 Kit: 14-006 USA



**American 85–  
 ADANAC**  
 Replace with: 98RH-20  
 Kit: 96-963 ADANAC USA  
 Kit: 96-922 CANADA



**Diebold Polaris  
 Over and Under**  
 Replace with: 98RH-20  
 Kit: 96-824 CANADA  
 Instructions: USA N/A



**Diebold Polaris  
 Side by Side**  
 Replace with: 98RH-20  
 Kit: 96-802 CANADA  
 Instructions: USA N/A



**Chubb "Q"**  
 Replace with:  
 98RH-20  
 Kit: 96-830 USA  
 Kit: 96-758  
 CANADA



**Diebold Securomatic  
 Trap**  
 Replace with: 98RH-20  
 Kit: 96-757 CANADA  
 Kit: 96-890 USA  
 Instructions: 96-757



**Chubb "Q"**  
 Envelope  
 (Right Side)  
 Replace with:  
 98RH-20  
 Kit: 96-939



**Chubb "Q"**  
 Without  
 Brass Trim  
 Replace with:  
 98RH-20  
 Kit: 96-862



**T With Lower Locker**  
 Replace with: 98RH-20  
 Kit: 14-029 CANADA  
 (With Lower Locker)  
 Kit: 14-030 USA  
 (With Lower Locker)  
 Kit: 14-037  
 (Lower Locker Only)  
 Kit: 96-798 CANADA  
 (With Out Lower Locker)  
 Kit: 96-959 USA  
 (With Out Lower Locker)  
 Kit: 96-973-TRIM (Trim only)  
 Kit: 96-972 (Locker cover only)



**Diebold Polaris  
 Over and Under  
 with Clearing Safe**  
 Replace with:  
 98RH-20  
 Kit: 96-956  
 Instructions:  
 USA N/A



**Eagle 103**  
 Replace with:  
 98RH-20  
 Kit: 14-180



**J-head**  
 Replace with:  
 98RH-20  
 Kit: 14-181



**Fortis 5084**  
 Replace with:  
 98RH-20  
 Kit: 14-188



**ACCESS**  
 Replace with:  
 98RH-20  
 Kit: 96-960  
 Instructions: N/A